


- SMONTAGGIO TELAIO
- UNCLIPPING THE FRAME FROM SLIDES
- ENLEVEMENT DU CADRE DES COULISSES
- RAHMENSDEMONTAGE
- COMO QUITAR EL BASTIDOR DE LAS GUIAS




Portata massima:
Maximum load:
Charge maxi:
Maximale belastbarkeit:
Carga maxima:

40
Kg


Istruzioni di montaggio

Assembling instructions
Notice de montage
Montageanleitung
Manual de montaje



AT41/55SM
AT55/69SM
AT69/83SM
AT83/97SM
AT97/110SM

10 min.	1		



PRIMA DI COMINCIARE, VEDERE I CONSIGLI DI MONTAGGIO

BEFORE STARTING, REFER TO THE ASSEMBLING ADVICE IN ANNEX

AVANT DE COMMENCER, SE REPORTER AUX CONSEILS DE MONTAGE EN ANNEXE

VOR DIE MONTAGE, BITTE BEILIEGENDE ANWEISUNGEN FOLGEN

ANTES DE EMPEZAR CONSULTE LOS CONSEJOS PARA EL MONTAJE

A x 1	B x 1	C x 1	D x 1	E x 1	F x 1	G x 1	H x 1
I x 1	L x 1	M x 2					
						Y x 2	Z x 8

